

# ECONO ROLL RETRACTABLE BANNER STAND


RETRACTABLE BANNER STANDS

PRODUCT CODE: ER24SLV, ER31.5SLV, ER33.5SLV, ER33.5BLK, ER36SLV

## SET UP INSTRUCTIONS


### Step 1

Twist the feet.




### Step 2

Assemble telescopic pole.



### Step 3

Insert telescopic pole into hole.




### Step 4

Pull banner out of the base.



### Step 5

Attach telescopic pole to the clamp bar.



### Step 6

Complete stand.

